



Water filling gate
When the water tank is filled with detergent liquid, please empty the water tank after usage.

